



QUIXDrive

Size 0 Single phase and three-phases

Manuale istruzione - Instruction manual
Manuel d'instruction - Handbuch
Manual de Instruccion

Le informazioni contenute in questo manuale possono essere modificate senza preavviso e non rappresentano impegno per la SIEI S.p.A. Per nessun motivo nessuna parte di questo manuale può essere riprodotta in qualsiasi forma o mezzo (compresa la registrazione e la fotocopia) senza il permesso scritto della SIEI S.p.A. La SIEI S.p.A. non è responsabile degli errori riscontrabili in questo manuale, nè dei danni che da essi possono derivare.

Prima dell'installazione, collegamento, messa in servizio e controllo dell'inverter, leggere attentamente il capitolo relativo alle istruzioni di sicurezza.

Tutti i diritti riservati.

The information held in this manual may be modified without notice and SIEI S.p.A. will not be responsible for changes that may occur in the future. No part of this manual can be reproduced, for any reason, in any form or by any means (including recording and photocopying) without the written consent of SIEI S.p.A.

SIEI S.p.A. is not responsible for those mistakes that may be found in this manual and for the damages that they may cause.

Before the inverter installation, wiring, commissioning and inspection, read the instruction section carefully.

All rights reserved.

Les informations contenues dans ce manuel peuvent faire l'objet de modifications sans avis préalable et SIEI S.p.A. décline toute responsabilité quant aux changements futurs pouvant avoir lieu.

Aucune partie de ce manuel ne peut être reproduite, pour quelque raison, sous quelque forme ou par quelque moyen que ce soit (y compris tout procédé d'enregistrement et de photocopie), sans l'autorisation écrite de la société SIEI S.p.A.

Avant l'installation, le câblage, la mise en service et l'inspection du convertisseur, veuillez lire attentivement ce manuel d'instructions.

SIEI S.p.A. décline toute responsabilité quant aux erreurs qui auraient été trouvées dans ce manuel et aux dommages qui pourraient en résulter.

Tous droits réservés.

Die in vorliegendem Handbuch enthaltenen Informationen können ohne Vorankündigung abgeändert werden und sind unverbindlich für die Firma SIEI S.p.A.

Ohne schriftliche Einwilligung der Firma SIEI S.p.A darf kein Teil dieses Handbuches in jeglicher Form oder mit jeglichem Mittel (einschließlich der Registrierung und der Fotokopie) reproduziert werden.

Die Firma SIEI S.p.A ist nicht verantwortlich für eventuell in diesem Handbuch enthaltene Fehler und daraus entstehende Schäden.

Vor Installation, Anschluss, Inbetriebnahme und Steuerung des Frequenzumrichters ist das Kapitel bzgl. der Sicherheitshinweise aufmerksam durchzulesen.

Alle Rechte vorbehalten.

La información contenida en el presente manual puede sufrir modificaciones sin previo aviso y no constituye ninguna obligación por parte de la SIEI S.p.A.

No está permitido reproducir, por ningún motivo, ninguna parte de este manual, en cualquier forma o por cualquier medio, (incluida la grabación y el fotocopiado) sin el permiso por escrito de SIEI S.p.A.

SIEI S.p.A. no es responsable de los errores que puedan encontrarse en este manual, ni de los daños que de éstos puedan derivarse.

Antes de la instalación, de la conexión, puesta en servicio y control del inverter, leer atentamente el capítulo relativo a las instrucciones de seguridad.

Reservados todos los derechos.

Sommario - Contents - Sommaire - Inhalt - Sumario

ITALIANO	1
PRESENTAZIONE	1
AVVERTENZE DI SICUREZZA	2
CARATTERISTICHE TECNICHE	3
Descrizione del prodotto	3
Guida alla selezione	3
SCHEMI DI COLLEGAMENTO	5
Morsettiera di potenza	5
Morsettiera di controllo	5
Collegamenti di controllo	6
INSTALLAZIONE	9
Norme per l'installazione	9
Pannelli di controllo	12
PARAMETRI DELL'INVERTER	15
Stato I/O digitali	16
Guida rapida ai parametri	17
Riferimento di frequenza	22
Descrizione funzionale	22
Caratteristica V / F	23
Salti di freq. - Limitazioni della freq. d'uscita - Jogging - Freq. di commutazione - Rampe di accel./decel.	24
Impostazione dati del motore - Protezione termica - Prevenzione stallo motore / Blocco inverter	25
Compensazione scorrimento - Sovraccarico istantaneo - Prevenzione buchi di rete - Ripresa motore in rotazione libera - Boost automatico ..	26
Ingressi di comando programmabili e non	27
Uscita a relè (OUT 1) - Frenatura dinamica	28
Uscita analogica (OUT-AN) - Frenatura in corrente continua	29
Regolatore PID	30
Reset - Autoreset - Protezioni e allarmi	31
Linea seriale	32
Ingresso analogico ausiliario (AUX-V) - Uscita analogica (OUT-AN)	33
ACCESSORI	34
Terminale remoto [codice QUIXREM]	34
Chiave di programmazione [codice QUIXPRG]	34
CONFORMITA' - NORMATIVE	35
Identificazione delle parti per l'installazione	36
Dimensioni e quote di foratura	36
ENGLISH	1
INTRODUCTION	1
SAFETY INSTRUCTIONS	2
Product description	3
THECNICAL FEATURES	3
Guide to the choice	3
TERMINAL BLOCK CONNECTIONS	5
Power section	5
Control section	5
Control connections	6
Power connections	6
INSTALLATION INSTRUCTIONS	9
Installation guidelines	9
Control panel	12
INVERTER PARAMETERS	15
I/o digital state	16
Parameters quick guide	17
Frequency reference	22
Function description:	22
V / F characteristic	23
Freq. jumps - Output freq. limitations - Jogging - Switching freq. - Accel./decel. ramps	24
Motor data setting - Motor thermal protection - Prevention of motor stall - inverter lock	25
Slip compensation - Instantaneous overload signalling - Prevention of short mains blackout - Pickup of motor in free rotation (flying restart) - Automatic boost	26

Programmable and non-programmable control inputs	27
Relay output (OUT-1) - Dynamic braking	28
Analog output (OUT-AN) - Direct current braking	29
PID regulator	30
Reset - Autoreset - Protections and alarms	31
Serial line	32
Auxiliary analog input (AUX-V) - Analog output (OUT-AN)	33
ACCESSORIES	34
Remote terminal [code QUIXREM]	34
Programming key [code QUIXPRG]	34
CONFORMITY - NORMS	35
Identification of the different installation sections	36
External dimensions	36
FRANÇAIS	1
PRÉSENTATION	1
INSTRUCTIONS DE SÉCURITÉ	2
SPÉCIFICATIONS TECHNIQUES	3
Description du produit	3
Table d'aide à la sélection	3
CONNEXIONS DES BORNERS	5
Plaque à bornes puissance	5
Plaque à bornes de commande	5
CONNEXIONS DE PUISSANCE	6
Connexions	7
INSTRUCTIONS D'INSTALLATION	9
Directives d'installation	9
PARAMÈTRES DU VARIATEUR	15
État E/S numériques	16
Guide rapide aux parametres	17
Référence de fréquence	22
Description fonctionnelle	22
Caractéristique tension/fréquence	23
Sauts de fréquence - Limit. fréquence de sortie - Marche par à-coups - Fréquence de commut. - Rampes accél. & décél.	24
Réglage données moteur - Protection thermique moteur - Prévention décrochage moteur - Verrouil. variateur	25
Compensation du glissement - Signalisation de surcharge instantanée - Prévention de microcoupures réseau - Reprise du moteur à rotation libre - Suralimentation automatique (boost)	26
Entrées de commande programmables et non	27
Sortie à relais (OUT-1) – Freinage dynamique	28
Sortie analogique (OUT-AN) - Freinage en courant continu	29
Régulateur PID	30
Remise à zéro (RAZ) - Remise à zéro automatique - Protections et alarmes	31
Ligne série	32
Entrée analogique auxiliaire (AUX-V) - Sortie analogique (OUT-AN)	33
OPTIONS	34
TERMINAL DISTANT [code QUIXREM]	34
CLÉ DE PROGRAMMATION [code QUIXPRG]	34
CONFORMITÉ - NORMES	35
Identification des différentes parties pour l'installation	36
Dimensions et cotes de perçage	36
DEUTSCH	1
EINFÜHRÜNG	1
SICHERHEITSHINWEISE	2
TECHNISCHE EIGENSCHAFTEN	3
Produktbeschreibung	3
Anleitung für die Modellauswahl	3
ANSCHLUSSBILD	5
LEISTUNGSKLEMMLEISTE	5
STEUERKLEMMLEISTE	5
LEISTUNGSANSCHLÜSSE	6

INSTALLATION	9
INSTALLATIONSVORSCHRIFTEN	9
BEDIENUNGSFELDER	12
FREQUENZUMRICHTER-PARAMETER	15
ZUSTAND DER DIGITALEN I/O	16
KURZEINFÜHRUNG DER PARAMETER	17
Frequenzsollwert	22
FUNKTIONSBESCHREIBUNG	22
U/f Eigenschaft	23
Frequ.sprünge – Begrenzungen der Ausgangsfrequ. – Jogging – Umschaltfrequenz– Beschl./Verzög.rampen	24
Einstellung Motordaten – Wärmeschutz – Verhütung von Motorüberziehen / Frequenzumrichterblockierung	25
Schlupfkompensation – Plötzliche Überlast – Netzausfallsverhütung – Motorwiederkehr in freier Drehung – Automatisches Boost	26
Programmierbare und nicht programmierbare Steuerungseingänge	27
Relaisausgang (OUT-1) - Dynamische Bremsung	28
Analogausgang (OUT-AN) - Gleichstrombremsung	29
PID Regler	30
Reset – Autoreset – Schutzeinrichtungen und Alarmer	31
Serielle Schnittstelle	32
Hilfs-Analogeingang (AUX-V) - Analogausgang (OUT-AN)	33
ZUBEHÖRTEILE	34
FERNTERMINAL [Code QUIXREM]	34
PROGRAMMIERUNGSSCHLÜSSEL [Code QUIXPRG]	34
KONFORMITÄT - BESTIMMUNGEN	35
Bestandteilidentifizierung für die Installation	36
Bohrungsabmessungen und -höhen	36
ESPAÑOL	1
PRESENTACIÓN	1
ADVERTENCIAS DE SEGURIDAD	2
Descripción del producto	3
CARACTERÍSTICAS TÉCNICAS	3
Guía de selección	3
ESQUEMAS DE CONEXIÓN	5
REGLETA DE POTENCIA	5
REGLETA DE CONTROL	5
CONEXIONES DE CONTROL	6
CONEXIONES DE POTENCIA	6
INSTALACIÓN	9
NORMAS PARA LA INSTALACIÓN	9
PANELES DE CONTROL	12
PARÁMETROS DEL INVERTER	15
ESTADO E/S DIGITALES	16
GUÍA RÁPIDA DE LOS PARÁMETROS	17
Referencia de frecuencia	22
DESCRIPCIÓN FUNCIONAL :	22
Característica V / F	23
Salto de frecu. - Limitaciones de frecu. de salida - jogging - frecu. de conmutación - rampas de acel./decel.	24
Configuración datos motor - protección térmica - Prevención parada motor / bloqueo inverter	25
Compensación deslizamiento - Sobrecarga instantánea - Prevención de microcortes de red	26
Entradas de mando programables y no programables	27
Salida por relé (OUT 1) - Frenado dinámico	28
Salida analógica (OUT-AN) - Frenado en corriente continua	29
Regulador PID	30
Reset - Autorreset - Protecciones y alarmas	31
Línea serie	32
Entrada analógica auxiliar (AUX-V) - Salida analógica (OUT-AN)	33
ACCESORIOS	34
TERMINAL REMOTO [código QUIXREM]	34
LLAVE DE PROGRAMACIÓN [código QUIXPRG]	34
CONFORMIDAD - NORMATIVAS	35
Identificación de las piezas para la instalación	36
Dimensiones y cotas de taladrado	36

Introduction

The QUIXDrive Inverters allow an efficient and flexible control of motor speed. In this way, the asynchronous motor can be used in a wider range of applications. The modern control systems allow a significant reduction of noise compared to the older inverters.

The QuixDrive is made of two different models:

- **QUIXDrive_F** single-phase and 3-phases, simple speed controller
- **QUIXDrive_V** single-phase and 3-phases, with a torque vector control

Noise disappearance:

The noiseless operation of the inverter is due to a proper method of creating the waveform of the voltage that supplies the motor.

Continuity of operation in power failure state:

In case of temporary power failure, the QUIXDrive inverter stops and starts again, and keeps the preset control characteristics without having to stop the motor.

Easy operation with the extractable keypad:

The functioning interface is made of a panel consisting of four keys, one display with four 7-segment digits and three leds.

The display and the keys allow you to change all the inverter parameters so as to make it suitable to all applications. The display also shows the controlled values, e.g. frequency or current, and the error codes in case of improper operation.

Serial connection:

Besides being controlled from panel, the QUIXDrive inverter can be easily remote controlled and programmed through serial connection by means of a proper communication protocol.

However, the run, stop, speed reversal and change operations are performed, as usual, through terminal board.

The QUIXDrive_V inverter supplies high torques at low revolution numbers without discontinuity thanks to the current automatic control. It assures a safe start of the motor.

General safety instructions

Throughout the text, the following **Danger symbols** indicate paragraphs containing particular instructions that must be carefully read so as to assure safety conditions to users:



This warns the user about the presence of a dangerous voltage. It indicates the presence of High Voltage conditions that can cause serious damages or even death.



This indicates a general danger or very important operation notes.



Warnings

- Electrical devices can represent a **risk source for personnel safety**. It is therefore necessary to know all usage methods and unit control devices perfectly before using the machine.
- The machine should then be used by skilled personnel only, aware of the installation and operation rules, in compliance with the safety and protection standards, and able to interpret all danger warnings. The capacitors contained in the machine have dangerous high voltages. After cutting power off, you should wait at least 5 minutes before performing any operation. With stopped motor, dangerous voltages can be present on the entire power terminal board: terminals **L1, L2, L3, U, V, W**.
- In particular adjustment programming conditions, after a power failure, the machine could start automatically.

Notes on Responsibilities

The unit is designed for motor speed control only. Do not use it for other applications. The manufacturer is not responsible for damages deriving from improper use or installation or inadequate ambient conditions, as well as for damages due to improper rated values. Nor will, the manufacturer be responsible for consequential or accidental damages.

No intervention has to be performed on parts inside the machine: when installing, just remove the terminal board cover panel. Any tampering or use of spare parts or other parts not supplied by the manufacturer, besides making the warranty void, may cause damages and/or serious accidents.

The technical data contained in this manual are to be considered correct at printout time. The manufacturer, however, reserves the right to change, without notice, both the contents and the technical data of the product.

Product description

The **QUIXDrive** inverters are converters with D.C. intermediate circuit. When connected with a common single or three-phase mains, they produce a three-phase, variable-frequency, A.C. voltage, used to control the speed of three-phase asynchronous motors.

The control circuit has a properly programmed microprocessor.

The control keyboard allows the user to easily and quickly enter any parameter necessary for the required working conditions.

The three-phase, variable frequency, alternate voltage, controlled by microprocessor, is delivered to the motor through a power module which uses the most recent IGBT technology.

The use of microprocessor, IGBT technology and modulation frequency programming, assures an extremely accurate and silent operation.

The software, properly developed for power electronics, allows an accurate and quick control of motor speed, start and stop times which can be independently adjusted, and other operation conditions:

- Speed control via the current adjustment according to the load, thus allowing the automatic adjustment to the process. (available in the QUIXDrive_V version).
- Automatic boost that allows a safe start of the motor by acting on the torque as a function of the load. Presence of high torques and rotation evenness at very low frequencies too. (available in the QUIXDrive_V version).
- Direct current braking, with programmable duration and value, allowing a comfortable motor stop.
- Presence of a PID-type inner regulator, which can be freely configured, to control the motor speed and/or torque.
- Presence of a standard series line, with programmable transmission modes, to remote program and/or control the converter.

Further, the unit is provided with a programmable relay output and an analog output that indicates, through selection, the trend of the main values of the inverter.

Guide to the choice


Model	Input voltage	Inverter power	Rated output current	Current absorption per phase	Motor power	Inverter dissipated power	Minimum braking resistor	Weight
	(Vac)	(kVA)	(A)	(A)	(kW)	(W)	(Ohm)	(kg)
QUIX.-2M-0004	220 V - 15%	1,0	2,2	4,5	0,37	25	100	1,5
QUIX.-2M-0007	240 V + 10%	1,6	3,9	8,0	0,75	45	100	
QUIX.-2M-0011	50 / 60 Hz	2,2	5,5	11,0	1,1	60	100	
QUIX.-2M-0015	single phase	2,9	7,0	14,0	1,5	80	50	
QUIX.-2T-0004	220 V - 15%	1,0	2,2	2,5	0,37	25	50	
QUIX.-2T-0007	240 V + 10%	1,6	3,9	4,4	0,75	45	50	
QUIX.-2T-0011	50 / 60 Hz	2,2	5,5	6,8	1,1	60	50	
QUIX.-2T-0015	3-phases	2,9	7,9	7,0	1,5	80	50	

Protection degree **IP 20**

Input voltage	single-phase, 220/240 V, tolerance -15%+10%; frequency from 47 Hz to 63 Hz.			
Output	voltage	three-phase from 0V to input voltage.		
	frequency	from 0.1 to 480 Hz; resolution 0.1 Hz (0,01 Hz if set via serial line). (switching frequency : from 1kHz to 18 kHz, programmable).		
	current	continuous output: nominal current of the inverter type . overload capacity : to 150% for 30" every 20'.		
	accel./decel.	acceleration time: 0.01" to 9999" deceleration time: 0.01" to 9999" " S " characteristic: 0.0" to 10.0"	via the terminal board it is possible to select up to 4 previously programmed ramp torques	
Environment conditions	ambient temp.: from 0°C to +40°C (temperture close to the inverter); storage temp.: from -20°C to +60°C ventilation: self or forced cooling according to the power; free of dust or corrosive gases humidity: from 20% RH to 90% RH, non-condensing installation: max. 2000 meters on the sea level (for higher levels, the features have to be derated) protection degree: IP 20			
External connections	Inputs	Digital optoisolated NPN or PNP	Operation signals	start (forward run), direction (reverse run), external alarm (the action is programmable). 2 other signals selectable between: alarm reset; frequency selector: F1, F2, F3; ramp selector: T1, T2; inverter enabling; d.c. braking enable; start or d.c. braking; flying restart.
		Analog	Frequency reference	selectable according to the voltage: 0/10V , -10V/+10V or to the current: 0/20 mA with programmable gain and offset
	Outputs	Indications	Relay	configurable for: alarm, inverter, frequency, ramp condition etc.
			Analog	0/10V: programmable gain and offset; the signal value can be proportional to: frequency, voltage, output current or torque, cos φ or output power.
	Serial	RS-485		2-wire operation: max. 32 inverters can be parallel-connected; the transmission parameters are programmable; it can be used to replace the keyboard panel
Protections	limits: overcurrent, overvoltage, undervoltage (with programmable threshold), inverter overtemperature; inverter overload, motor overload (QUIX_V), braking resistance overload, inner fuse cutoff, phase to phase and phase to ground shortcircuit, error in the values of the stored parameters.			
Standard functions	programmable V/f characteristic, slip compensation (QUIX_V), autoreset (programmable intervention time and retry number), jump frequency, upper and lower frequency limits, flying restart (QUIX_V), power "dips" prevention (QUIX_V), PID regulator, motor stall (QUIX_V) or inverter fault prevention, overmodulation, potentiometer function.			

(QUIX_V) : available in the QUIXDrive_V version


Power section



POWER SUPPLY:

Single-phase (L, N) 220V (-15%) ...240V (+10%), 50/60Hz +/- 2Hz
 3-phases (L1, L2, L3) 220V (-15%) ...240V (+10%), 50/60Hz +/- 2Hz

Control section



Note: voltage input can be used as main speed reference or auxiliary input with the meaning of P47


Power connections

TERMINALS	FUNCTION
PE	GROUND CONNECTION
L1 (L) L2 (N) L3	MAINS POWER SUPPLY: 220...230V SINGLE-PHASE (L, N), 220...230V THREE-PHASES (L1, L2, L3)
R	BRAKING RESISTANCE
+DC	Positive of the d.c. circuit
PE	POWER GROUND
U V W	THREE-PHASE OUTPUT (TO THE MOTOR)

Control connections


TERMINALS	N.	FUNCTION		SIGNAL TYPE	
REV	1	Reversal	Se b-00=1 :	Optical couplers: 24 V, 6 mA	
RUN	2	Run			Backward run
EXTFLT	3	Alarm from outside			
IN5	4	Configurable digital input	P-43		
CM-IN	5	Digital input common			
+24 V	6	Aux. power supply for digit. inputs			24 V +/- 5% 300 mA
GND-D	7	Reference ground for digit. inputs			
LNK+	8	RS-485 serial line inputs			
LNK-	9				
EARTH	10	Ground connection			
IN4	11	Configurable digit. input	P-42	Optical coupler: 24 V, 6 mA	
OUT-AN	12	Configurable anal. output	P-48	0 - 10 V $R_{load\ min} = 2\ k\Omega$	
+10V	13	Potentiometer voltage for speed ref.		10 V +/- 5% 10 mA	
IN-Analog	14	Anal. input for speed ref. (J 11)		0 - 10 V or +/- 10 V $R_i = 20\ k\Omega$; 0 - 20 mA $R_i = 250\ \Omega$	
GND-A	15	Common for analog input/output circuit			
OUT1-NC	16	Contacts of the configurable output relay		120 V ac with 0.5 A or 24 V dc with 1 A	
OUT1-CM	17				P-44
OUT1-NO	18				

Connections




NOTE : The connections stated for the control keys are the most common solution for a NPN control. Other examples are given on the following page.

Connections for PNP controls:



Connections for controls which are opto-isolated from the inverter:



INSTALLATION GUIDELINES



In order to obtain a safe operation of the unit, assembly and start-up should be performed by skilled personnel only, according to the general regulations concerning safety conditions when working with high currents or voltages.

• Mechanical installation

Removal of the heat produced by the inverter is performed by ventilating with natural air flow, in low power models, and by means of fan in all other models.

When assembling, leave a space of at least 40 mm. from the sides and, on the heatsink side, 150 mm. above and below the inverter, so as to assure a free circulation of the cooling air. In case of stacking of more units, leave a vertical space of at least 300 mm. between them.

The site should assure the ventilation air is free from dust or corrosive gases, otherwise a regular cleaning of the cooling surfaces must be performed. Avoid, in any case, the condensation of the sprayed fluids. The ambient humidity should never exceed 90%.

In working conditions, the temperature inside the cabinet should never exceed **40° C**. If it should, it will be necessary to perform a derating of the unit or a forced ventilation so as to avoid air stagnation.



Warning: When calculating the overall dimensions, also consider the space required for installation of anti-noise filters.

• Electrical installation

The inverters are designed to operate in an industrial environment where high levels of electro-magnetic disturbance (EMI) must be expected. Good installation practice usually ensure trouble-free operation, however it is suggested that a good ground connection and RFI filters should be used. The RFI filters ensure a reduction of radiated or conducted interference when the inverter is in a interference sensible environment. The instructions on the following page show how to perform the wiring in order to be in compliance with the EMC norms.

In order to connect the inverter, just remove the cover which protects the power and control terminal boards; it can be removed by acting on the clip placed on the front upper side of the cover itself.

The **QUIXDrive** series is foreseen for a single-phase or three-phases 220/240V power supply.

As for the power supply cables, we recommend to use two or three-wire shielded cables where the ground cable is external and parallel to the shield; their dimensions must follow the values listed on page 10.

The same cable can be used for motor connection too. The cable length should never exceed **30 m**. If it should, use additional inductances, series-connected with cables, to balance the parasitic capacities. In this case, a reduction of motor voltage can be noticed.



Warning: The inverter power supply must be protected by means of fuses or automatic switches. Make sure the cables are properly connected and, in particular, check that the ground connection is correctly locked.

In case of shielded power supply cables, ground connect the shield on both sides.

The power cables must be kept separate from the signal cables. The standards require the use of separate raceways.

For control cables, use a shielded cable with a section of at least 0.5 mm². The **shield** should be connected to the **terminal 10** on drive side only.

For connection of reference signals or serial line, use twisted cables.

Connect spark quenching units in parallel to relay coils, solenoid valves, remote control switches located near the unit, as suggested on the following table:

REMOTE CONTROL SWITCH
OR SOLENOID VALVE

CHARACTERISTICS OF SPARK QUENCHING UNIT

220 V, 240 V	>30 A	0.5uF + 100Ohm 1/2 W	250 V
220 V, 240 V	<30 A	0.1uF + 100Ohm 1/2 W	250 V



Warning: The failure protection circuit towards earth must **ONLY** protect the inverter against failures towards earth, occurring on the motor cable or on the motor itself. It is **NOT** designed to protect people who accidentally touch the motor or the corresponding supplying cable.

It is forbidden: to connect PFC devices to output terminals between inverter and motor;
to connect capacitors between output terminals or output terminals and earth;

Note: It is not advisable to connect remote control switches to output terminals between inverter and motor if, while their functioning phase, both the motor and the inverter are running.


Wiring - Protections - Cables

NB.: To connect the inverter it is necessary to conform to the following indications:

- 1 - As for the power connections, the shielding must include only the two power conductors; the ground wire, **which is obligatory**, must be external to the shield and run parallel to it.
- 2 - Both the inverter side and the motor or filter side of the shield must be grounded.
- 3 - The ferrite toroid must be put on the inverter side of the cable in a way to cover the part of the cable uncovered from the shield.
- 4 - The power cables must be kept separated from the signal cables; it is forbidden to install power and signal cables in the same conduit or duct. It is important to hold motor wiring as far as possible from the power supply wiring.
- 5 - Use high quality motors, with low parasitic capacities towards ground.

The input filter increases leak currents towards ground; so it is advisable use a overcurrent switch with a tripping current not lower than 100 mA .

The figure shows the wiring method in compliance with the stated standards by using an external filter.



Protections and cable sections

Model	Line current	Suggested line fuse		Min. section Power supply and motor cables
	(A)	(Jean Muller type)	Code	
QUIX.-2M-0004	4,5	GRD2-10	F4D13	1,5
QUIX.-2M-0007	9,0	GRD2-16	F4D14	1,5
QUIX.-2M-0011	12,0	GRD2-20	F4D15	3,0
QUIX.-2M-0015	16,0	GRD2-25	F4D16	4,0
QUIX.-2T-0004	2,5	GRD2-6	F4D12	1,5
QUIX.-2T-0007	5,0	GRD2-10	F4D13	1,5
QUIX.-2T-0011	8,0	GRD2-16	F4D14	1,5
QUIX.-2T-0015	9,0	GRD2-16	F4D14	2,5

The stated cable section is the minimum one when the length is not higher than 30 m.

In this way the losses are limited and the power drops do not exceed 5% of the power supply voltage as specified by the EN60204-1 norms.

Operation



WARNING Before turning the inverter on, make sure the cover is locked in position. After each turning off, wait 3 minutes before opening the unit so as to allow the capacitors to discharge.

For safety reasons, at power on or after a reset due to an alarm, the inverter is factory-preset not to start even with run control in active state. To start the motor, you should set the control first to OFF and then to ON (this safety precaution can be intentionally cancelled through **b-03** parameter).

Turning on

The inverter is not provided with an ON/OFF switch. This operation is performed by applying the mains voltage. After voltage application, the inverter performs a test.

If an error is encountered during this test, the display will show the message **Err**

The display, consisting of four 7-segment digits, shows both letters and numbers. When turned on, it shows the output frequency value (**00** Hz if the motor is stopped).

The inverter is factory-preset to control three-phase asynchronous motors which operate with voltages and currents having values corresponding to the inverter size.

Run

- 1 - Connect a 4.7 kOhm potentiometer for the speed reference (terminals 13,14,15)
- 2 - Power supply the digital inputs (terminal 5) with +24V. If the inputs have not to be isolated, it is possible to use the power supply available on the terminal 6.
- 3 - Connect two contacts for forward and backward run control (terminals 2, 1, and 7/8) as shown on page 6.
- 4 - Close the run contact to start the motor . The motor is started at the frequency selected through the preset ramp (default P-05= 5 seconds).



WARNING If the factory - preset values should be modified to adapt the inverter to the application, it can be made through the control panel where the actual values can be displayed, then modified, and then permanently stored.

In case it is needed, the default values can be reset via the C02 function

Stop

To stop the motor, act as follows:

- Disable the run control. In this way, the motor is stopped with factory-preset ramp (P-06= 5 seconds from max. frequency to 0 Hz).
- Or set to zero the speed reference potentiometer, so that the user has control over the motor stop.

Caution: in this case the motor, even though it is stopped, is still under voltage.

The motor does not start

If after enabling the run control, the motor does not start, first check that the connections shown on the previous pages have been performed, then check that the factory-preset parameters meet the motor characteristics.


The parameter check is performed by using the keypad: press the **M** key until the **P** menu appears , then, through the **↑**, **↓** keys select the code of the parameter with the value to be checked and press the **E** key to read its value. The data of the motor rating characteristics are important; they can be set via the parameters P-01, P-02, P-09, P-11, P-12.

Caption of the function leds mounted behind the front cover


yellow	: POWER
green	: RUN
red	: ALARM

Control panel

● Removable auxiliary keyboard [code : QUIX-TST]



● Removable keyboard [code QUIXF-TST]:



The Leds and the Keys of the Extractable Keypad have the same meaning and perform the same functions of the Auxiliary Keyboard, with exception of the indication of the unit of measures.



Caution: the changes made to parameter values have an immediate effect but are not automatically stored. The storage is performed through the **C-00** control.

(*) **NOTE:** the **flashing of Green Leds** indicates the action of the motor stall or inverter fault prevention.

- **The display** is used to show both letters and numbers, e.g.:


P-xx means: **P** = letter indicating the selected menu
xx = numeric code indicating the parameter progressive number

xxx.x means: number, also decimal, indicating the value of the selected parameter


- The parameter sets, or **MENUS**, have the following meaning:

d-xx menu of the read-only parameters (display)
F-xx menu of the read/write parameters of the terminal board selectable frequencies
P-xx menu of the read/write parameters
b-xx menu of the read/write parameters, ON/OFF type (they can be changed with a stopped motor only)
C-xx menu of control-type parameters


At the start-up, the control panel enters the MONITOR mode thus allowing to read the values assumed by the **d** parameters. The chart shows how to switch from one menu to the other and how to act on the parameters inside the menus.



To **CHANGE** a parameter value: **DISPLAY** the corresponding code, then confirm via the **E** key as stated by the following chart:



Act as follows to **STORE permanently** the performed changes:



Changing the parameters

• Procedure for a parameter change:

Let us assume we turn the inverter on and we want to change the value of the max. working frequency from 50 Hz (factory-preset value) to 100 Hz.

- At start-up: ON DISPLAY 00
- 1 - Press **M** repeatedly until the **P** menu is displayed: ON DISPLAY P-00
- 2 - Through the **↑ ↓** keys select the code **01** ON DISPLAY P-01
 and press **E**;
 the value of the **P-01** parameter is displayed (max. frequency) ON DISPLAY 500
- 3 - Note the state of PRG LED (page 13): if it is permanently lit, the parameter can be modified. Press **↑** to increase the number, **↓** to decrease it; (if the key is held down, the digit scan speed is increased).
 Now, press **↑** till the display shows **100.0** ON DISPLAY 1000
 Press **E** to confirm and enable the value;
 (the parameter is displayed again)..... ON DISPLAY P-01

NOTE: In this way, the value of max. frequency has been changed, but not stored in a permanent way (Yellow LED is flashing).


- 4 - Press **M** until the **C** menu is displayed; through the **↑ ↓** keys select the code **00**; ON DISPLAY C-00
 press **E** to confirm the selection;
 the PRG LED, if permanently lit, indicates the storage enabling.
 Through the **↑ ↓** keys enter the code **7** ON DISPLAY 7
 Press **E** to confirm the value;
 the message "**donE**" is displayed for 2 seconds to confirm the operation..... ON DISPLAY donE
 The storage operation is completed.

Parameter display:

At the start-up the inverter enters the monitor mode: the **d MENU** is active, which allows to read the values acquired by the different unit of measures, as stated in the table; first, the output frequency parameter is displayed. The same action is obtained by selecting the **d MENU** via the **M** key.

To facilitate the commissioning, the parameters, which can be modified, are divided into three groups or levels. Whether the parameters of a given level (accessibility) can be changed or not depends on the presetting of the **P-20** parameter:

- P-20=1 → 1st level (factory setting)
- P-20=2 → 2nd level
- P-20=3 → 3rd level


CODE	DESCRIPTION	CHANGE RANGE	UNIT	PRESET VALUE
d-00	output frequency	0.1 Hz		
d-01	reference frequency	Fmin.to Fmax.	0.1 Hz	
d-02	output current (rms)(QUIX_V)		0.1 A	
d-03	output voltage (rms)		1 V	
d-04	continuous voltage (dc)		1 V	
d-05	output speed (d-00)*(P-16)		0.01 / 1	
d-06	reference speed (d-01)*(P-16)		0.01 / 1	
d-07	cosφ(QUIX_V)		0.01	
d-08	power(QUIX_V)		0.01 Kw	
d-09	inverter overload (100% = alarm threshold)(QUIX_V)		0.1 %	
d-10	motor overload (100% = alarm threshold)(QUIX_V)		0.1 %	
d-11	braking resistance overload (100% = alarm threshold)		0.1 %	
d-12	last alarm memory	to reset the alarms use the [-03] control		
d-13	second to last alarm memory			
d-14	third to last alarm memory			
d-15	fourth to last alarm memory			
d-16	digital input state		each vertical segment corresponds to an input or output state, as shown in the table on next page	
d-17	digital output state			
d-18	/			
d-19	/			
d-20	/			
d-21	/			
d-22	pid reference		0.1 %	
d-23	pid feedback		0.1 %	
d-24	pid error		0.1 %	
d-25	pid integral component		0.1 %	
d-26	pid output		0.1 %	
d-27	inverter rated current		0.1 A	
d-28	software version	xx.xx		
d-29	identification code (config. file)	xxxx		
d-30	display test	all segments are on		

(QUIX_V) : parameter available in the QUIXDrive_V version


I/o digital state

NOTE.: Each segment, when lit, indicates that the corresponding input or output are active

- Inputs:



- Outputs:



Parameters quick guide

F menu: it sets and/or reads the frequencies that can be selected through the terminal board

CODE	DESCRIPTION	RANGE	UNIT	PRESET VALUE	PAGE
F - 00	Reference frequency 0	0.0 / 480.0	0.1 Hz	0.0	22
F - 01	Reference frequency 1	" "	" "	" "	"
F - 02	Reference frequency 2	" "	" "	" "	"
F - 03	Reference frequency 3	" "	" "	" "	"
F - 04	/				
F - 05	/				
F - 06	/				
F - 07	/				
F - 08	Jogging frequency	" "	" "	1.0	24

C menu: it sets and executes some controls: to execute them, select value **7** and confirm via **E**.

CODE	PERFORMED ACTION
C - 00	Permanent storage of all parameters (*)
C - 01	Recall of previously stored parameters (the currently used parameters are replaced by the previously stored ones) (*)
C - 02	Recall of the factory-set parameters (the storage depends on the operator's choice) (*)
C - 03	Zero setting of the alarm memory
C - 04	Recall and storage of the parameters contained in the external programming key [from key to Inv.] (*)
C - 05	Storage of the inverter parameters on the external programming key [from Inv. to key]
C - 06	Measure of motor phase resistance and corresponding initialization of parameter P - 12 (page 25) (QUIX_V)(*)

(QUIX_V) : parameter available in the QUIXDrive_V version



Caution: all parameters or part of them can be write-protected through **P - 19** parameter; In case of a non-authorized modification attempt or with a running motor, the following message will be displayed: **Prot** .

NOTE: All parameters, which are not listed in the tables, are reserved for future developments; as a consequence, they must be always set to 0.

PARAMETER	VAL	PERFORMED ACTION
P - 19	0	no protection
P - 19	1	F non-protected parameters , the others are protected
P - 19	2	all parameters are protected
P - 19	3	no protection; storage possibility with running motor too; not recommended

NOTE: The sign (*) means that the controls can not be executed with running motor

For safety reasons the **P** parameters, which can be changed, are divided into three groups or levels. Whether the parameters of a given level (accessibility) can be changed or not depends on the presetting of the **P-20** parameter:

- P-20=1 → 1st level (factory setting)
- P-20=2 → 2nd level
- P-20=3 → 3rd level

INVERTER PARAMETERS

P menu: it sets all the values of the inverter parameters; they are divided into three groups or LEVELS; their access depends on the code (1, 2, 3) set via the **P - 20** parameter.

CODE	DESCRIPTION	RANGE	UNIT	P R E S E T VALUE	PAGE
Level 1					
P - 00	reference setting	0 - 4 ; 9	1	0	22
P - 01	maximum frequency	50.0 - 480.0	0.1 Hz	50.0 (*)	"
P - 02	maximum output voltage	(P-72) - (**)	1 V	(**)	(*) 23
P - 03	V/F characteristic type	0 - 4	1	1 (*)	"
P - 04	torque boost at low revolutions (boost)	0 - 30	1% di (P-02)	3	"
P - 05	acceleration time 1	0.01 - 9999	0.01 / 0.1 / 1 s	5.0	24
P - 06	deceleration time 1	0.01 - 9999	0.01 / 0.1 / 1 s	5.0	"
P - 07	"S" curve characteristic (S)	0.0 - 10.0	0.1 s	0,0	"
P - 08	modulation frequency	0 - 7	1	5 (*)	"
P - 09	motor rated current (QUIX_V)	(20% -150%)Inom	0.1 A	Inom	25
P - 10	motor thermal constant (QUIX_V)	1 - 120	1 min.	20	"
P - 11	rating of motor cos φ (QUIX_V)	0.01 - 1.00	0.01	(**)	"
P - 12	motor stator resistance (QUIX_V)	0.0 - 25.0	0.1 ohm	0,0	"
P - 13	motor efficiency (QUIX_V)	0 - 100%	1	100	"
P - 14	min. frequency (offset) for frequency analog reference	-480 /+480	1 Hz	0	22
P - 15	gain for frequency analog reference	0.00 - 9.99	0.01	1.00	"
P - 16	conversion constant (***)	0.01 - 99.99	0.01	1.00	15
P - 17	display message setting at start-up (value of d-xx)	0 - 30	1	0	"
P - 19	parameter protection code	0 - 3	1	0	"
P - 20	programming level	1 - 3	1	1	"
Level 2					
P - 21	acceleration time 2	0.01 - 9999	0.01 / 0.1 / 1 s	5.0	24
P - 22	deceleration time2	0.01 - 9999	0.01 / 0.1 / 1 s	5.0	"
P - 23	acceleration time 3	0.01 - 9999	0.01 / 0.1 / 1 s	5.0	"
P - 24	deceleration time 3	0.01 - 9999	0.01 / 0.1 / 1 s	5.0	"
P - 25	acceleration time 4 / jogging accel. time	0.01 - 9999	0.01 / 0.1 / 1 s	5.0	"
P - 26	deceleration time 4 / jogging decel. time	0.01 - 9999	0.01 / 0.1 / 1 s	5.0	"
P - 27	resolution for accel. / decel. ramps	0=0.01s 1=0.1s 2=1s	1	1	"
P - 28	DC braking level	0 - 100	1% di Inom	0	29
P - 29	frequency for DC braking enabling	0.0 / 480.0	0.1 Hz	0.0	"
P - 30	DC braking time at start	0.0 - 60.0	0.1 s	0.0	"
P - 31	DC braking time at stop	0.0 - 60.0	0.1 s	0.0	"
P - 32	slip compensation (QUIX_V)	0.0 - 25.0	0.1 %	0.0	26
P - 33	time constant of slip compensation (QUIX_V)	0.0 - 10.0	0.1 s	0.1	"
P - 34	jump frequency 1	0.0 / 480.0	0.1 Hz	0.0	24
P - 35	jump frequency 2	0.0 / 480.0	0.1 Hz	0.0	"
P - 36	jump amplitude	0.0 - 100.0	0.1 Hz	0.0	"
P - 37	output frequency upper limit	(P-38) - 110	1% di (P-01)	100	"
P - 38	output frequency lower limit	0 - (P-37)	1% di (P-01)	0	"
P - 39	/				
P - 40	/				
P - 41	/				
P - 42	IN4 input configuration	0 - 17	1	4	24/27
P - 43	IN5 input configuration	0 - 17	1	0	"

NOTE: (*) the controls can be executed with stopped motor only (**) the parameter values depend on the inverter size
 (***) the coefficient allows to convert the frequency displayed in d-00 into output speed for P-05 and P06
 (QUIX_V) : parameter available in the QUIXDrive_V version

P menu:

CODE	DESCRIPTION	RANGE	UNIT	PRESET VALUE		PAGE
Level 2						
P-44	OUT-1: output configuration	0 - 35	1	2	(*)	28
P-45	/					
P-46	/					
P-47	IN-analog : analog input configuration	0 - 11	1	0		33
P-48	analog output configuration	0 - 17	1	0	(*)	29
P-49	analog output offset	-9.99 / +9.99	0.01 V	0.00		"
P-50	analog output gain	-9.99 / +9.99	0.01	1.00		"
P-51	analog output time constant	0.00 - 2.50	0.01 s	0.00		
P-52	/					28
P-53	signalling frequency	0.0 - 480.0	0.1 Hz	0.0		"
P-54	hysteresis amplitude related to P-53	0.0 - 100.0	0.1 Hz	0.5		28
P-55	current limit for overload (QUIX_V)	20 - 200	1%(mot.)	110		"
P-56	delay time for overload signalling (QUIX_V)	0.1 - 25.0	0.1 s	0.1		31
P-57	autoreset time	0.1 - 60.0	0.1 s	5.0		"
P-58	number of autoreset attempts	1 - 250	1	1		
P-59	/					
P-60	/					
P-61	/					28
P-62	ohmic value of the braking resistance	1 - 250	1 ohm	(**)		"
P-63	braking resistance power	10 - 2500	10 W	(**)		"
P-64	braking resistance thermic constant	5 - 1250	5 s	(**)		32
P-65	input setting by serial line enabling	0 - 255	1	0		"
P-66	output setting by serial line enabling	0 - 15	1	0		"
P-67	serial line configuration	0 - 19	1	1		"
P-68	serial line address	0 - 99	1	0		"
P-69	response delay time on serial line	0 - 250	1 ms	1		23
Level 3						
P-70	basic frequency	(P-71) - 480.0	0.1 Hz	50.0	(*)	"
P-71	V / F intermediate frequency	0 - (P-70)	0.1 Hz	25.0	(*)	"
P-72	V / F intermediate voltage	0 - (P-02)	1 V	(**)	(*)	"
P-73	ramp start/stop frequency	0 - 25.0	0.1 Hz	0.0	(*)	"
P-74	output voltage reduction	0 - 100	1%(P02)	100		26
P-75	undervoltage threshold	40 - 80	1%(P02)	70	(*)	"
P-76	max. time of short mains blackout (QUIX_V)	0.1 - 25.0	0.1 s	1.0	(*)	25
P-77	accel. current limit for f<f_base (QUIX_V)	20 - 200	1%(Inom)	170		"
P-78	accel. current limit for f>f_base (QUIX_V)	20 - 200	1%(Inom)	170		"
P-79	current limit at constant speed (QUIX_V)	20 - 200	1%(Inom)	170		26
P-80	current limit for motor pickup (QUIX_V)	20 - 200	1%(Inom)	120		"
P-81	demagnetization time	0.01 - 10.00	0.01 s	(**)		25
P-82	decel. speed to prevent stall at constant speed (QUIX_V)	0.1 - 25.0	0.1 s	1.0		26
P-83	frequency scan time during motor pickup (QUIX_V)	0.1 - 25.0	0.1 s	1.0		23/26
P-84	voltage reset time	0.1 - 25.0	0.1 s	0.2		25
P-85	tolerance at constant speed	0.1 - 25.0	0.1 Hz	0.5		"
P-86	ramp end delay/constant speed	0.1 - 25.0	0.1 s	1.0		
P-87	magnetization current compensation gain (QUIX_V)	0 - 100	1	0		
P-88	magnetiz. current compens. time constant (QUIX_V)	0 - 3	1	0		32
P-89	reception time out (serial communication) [off if 0,0]	0.0 - 25.0	0.1	0.0		

NB. : (*) the controls can be executed with stopped motor only; (**) the values depend on the inverter size.
 (QUIX_V) : parameter available in the QUIXDrive_V version

P menu:

CODE	DESCRIPTION	RANGE	UNIT	P R E S E T VALUE	PAGE			
Levello 3								
P - 90	PID reference	0,0 - 100,0	0,1 %	0,0	30			
P - 91	PID max. positive error	0,1 - 100,0	0,1 %	5,0	"			
P - 92	PID max. negative error	0,1 - 100,0	0,1 %	5,0	"			
P - 93	PID updating time	0,00(=0,005s) - 2,50	0,01 s	0,00	"			
P - 94	proportional term gain	0,00 - 99,99	0,01	0,00	"			
P - 95	integral action time					0,01	99,99	"
P - 96	derivative action time					0,01	0,00	"
P - 97	proportional term gain	0,00 - 99,99	0,01	0,00	"			
P - 98	integral action time					0,01	99,99	"
P - 99	derivative action time					0,01	0,00	"

NOTE : (*) the controls can be executed with stopped motor only; (**) the values depend on the inverter size.

b menu:

It sets the values of ON / OFF parameters; they are divided into three groups, or LEVELS, their access depends on the code (1, 2, 3) set via the **P - 20** parameter. **They all can be modified with stopped motor only**

CODE	DESCRIPTION	RANGE	UNIT	P R E S E T VALUE	PAGE
Level 1					
b - 00	run/reversal input configuration	0=RUN/REV	1=FWD/REV	0	24
b - 01	stop mode	0=in ramp	1=coast	0	27
b - 02	reversal enabling	0=off	1=on	1	"
b - 03	protection	0=off	1=on	1	"
b - 04	reference input reversal	0=off	1=on	0	22
b - 05	current input	0=0/20mA	1=4/20mA	1	22
b - 06	enabling of motor overload protection (QUIX_V)	0=off	1=on	1	25
b - 07	motor type (QUIX_V)	0=standard	1=servoventilated	0	"
b - 08	configuration of external alarm input	0=NO(nor. open)	1=NC(nor.closed)	0	27
b - 09	external alarm tripping mode	0=alarm/lock	1=inverter disabl.	0	"
b - 10	external alarm detection mode	0=always	1=run only	0	"
Level 2					
b - 11	autoreset handling in case of external alarm	0=off	1=on	0	"
b - 12	autoreset enabling	0=off	1=on	0	27/31
b - 13	enabling of autoreset attempt limitation	0=off	1=on	0	31
b - 14	enabling of autoreset of auto zero-setting attempts	0=off	1=on	0	"
b - 15	autoreset alarm contact	0=off	1=on	1	31
b - 16	voltage reduction tripping mode	0=always	1=con. sp. only	0	23
b - 17	enabling of momentary overload control (QUIX_V)	0=off	1=on	0	26
b - 18	tripping mode of momentary overload control (QUIX_V)	0=always	1=con. sp. only	0	"
b - 19	enabling of momentary overload alarm (QUIX_V)	0=off	1=on	0	"
b - 20	enabling of braking resistance overload protection	0=off	1=on	0	28
b - 21	/				
b - 22	/				
b - 23	/				
Level 3					
b - 24	stall prevention during acceleration (QUIX_V)	0=off	1=on	1	25
b - 25	stall prevention at constant speed (QUIX_V)	0=off	1=on	1	"
b - 26	stall prevention during deceleration	0=off	1=on	1	"
b - 27	overvoltage prevention	0=off	1=on	0	"

20-GB (QUIX_V) : parameter available in the QUIXDrive_V version

b menu:

CODE	DESCRIPTION	RANGE	UNIT	PRESET VALUE	PAGE
Level 3					
b - 28	prevention of short mains blackout (QUIX_V)	0=off	1=on	0	26
b - 29	motor pickup enabling (flying restart) (QUIX_V)	0=off	1=on	0	"
b - 30	scan start frequency for pickup control (QUIX_V)	0=reference freq.	1=max. freq.	0	"
b - 31	motor pickup at start-up (QUIX_V)	0=off	1=on	0	"
b - 32	automatic adjustment of output voltage	0=off	1=on	1	23
b - 33	dead times compensation (QUIX_V)	0=off	1=on	1	24
b - 34	automatic boost enabling (QUIX_V)	0=off	1=on	0	26
b - 35	/ not used				
b - 36	enabling of switching frequency reduction under 5 Hz	0=off	1=on	0	24
b - 37	enabling of undervoltage alarm storage	0=off	1=on	1	31
b - 38	overmodulation for f > f base (torque increase)	0=off	1=on		
b - 39	terminal board control enabling	0=off	1=on	1	
b - 40	PID regulator enabling	0=off	1=on	0	27/30
b - 41	regulator tripping mode	0=running	1=const. speed run	0	30
b - 42	/				
b - 43	variable adjusted by PID regulator	0=frequency	1=voltage	0	30
b - 44	error sign reversal	0=off	1=on	0	"
b - 45	adjustment mode	0=direct	1=sum(feed/forw.)	0	"
b - 46	suppression of PID regulator positive output	0=off	1=on	0	"
b - 47	suppression of PID regulator negative output	0=off	1=on	0	"
b - 48	suppression of positive or negative integral term	0=off	1=on	0	"
b - 49	integral term initialization at start	0=off	1=on	0	"
b - 50	} PID reference input switches	see following table		0	"
b - 51				0	"
b - 52				0	"
b - 53	} PID feedback input switches	see following table		1	"
b - 54				0	"

(QUIX_V) : parameter available in the QUIXDrive_V version

	feedback switches				reference switches		
	b - 55	b - 54	b - 53		b - 52	b - 51	b - 50
	-	-	-	ref. frequency	0	0	0
/ not used	0	0	1	/ not used	0	0	1
/ not used	0	1	0	/ not used	0	1	0
In-Analog	0	1	1	In-Analog	0	1	1
/ not used	1	0	0	REF-I	1	0	0
	-	-	-	parameter P-90	1	0	1
	-	-	-	freq. after ramp	1	1	0
current	1	0	1	generator	-	-	-
torque	1	1	0		-	-	-
power	1	1	1		-	-	-
set to 0	0	0	0	set to 0	1	1	1

Note: If IN-Analog is configured as voltage, it can be used as main frequency reference or auxiliary input (AUX-V) (depending on P47 setting)

Function description:

Frequency reference



PARAMETER	FUNCTION	RANGE [DEFAULT]	VALUE	DESCRIPTION	ASSOCIATED PARAMETERS	
P-00	Determines the inverter operation frequency	0 - 4 [0] the values 5,6,7,8 are not used		Each parameter value correspond to a different reference:		
				0	analog input: REF-V (0/10V with 1-2 in J11: 0-20mA with 2-3)	P-01 P-14 P-15 b04
				1	analog input: REF-V (-/+10V) - the polarity states the rotation direction	
				2	Analog input: REF-I (0/20mA [b-05=0] or 4/20mA [b-05=1])	
				3	it selects the frequency set by the F-00 parameter	
				4	input from serial line with 0.01 Hz resolution	
9	motorized potentiometer reference					
P-01	Indicates the max. operation frequency	50.0 - 480.0 [50,0] (Hz)		The set value is the full scale value for the analog inputs and for the variables of the F menu.		

When selecting the analog input, it is possible to change the formula that transforms the reference input signal into the motor supply frequency through the following parameters:



- P-14** determines the minimum frequency (offset); it can assume negative values too.
- P-15** it is a gain multiplicative factor $G = P15 * (P01 - P14) / 10$.
- b-04** enables the formula reversal (a minimum signal corresponds to a maximum frequency).

Example: with P-00 = 1 the reference is the voltage analog signal type 0/10 V:

Direct formula: **b-04=0**



Inverse formula: **b-04=1**



In any case Frif is always limited between P-73 and P-01.

By configuring the two digital inputs as frequency switches (P42=1 and P 43=2), it is possible to recall the frequencies set via the **F** parameters:


INPUTS		DESCRIPTION
In SF1	In SF2	P-00 = 0 o P00 = 1
0	0	the reference frequency is read by the analog input
1	0	the frequency reference is the frequency F-01
0	1	the frequency reference is the frequency F-02
1	1	the frequency reference is the frequency F-03

NOTE.
in the table:
1 means closed contact,
0 means open contact;
a non-used input is considered as 0.

V / F characteristic						
PARAMETER	FUNCTION	RANGE [DEFAULT]	VALUE	DESCRIPTION	ASSOCIATED PARAMETERS	
P-03	Determines the voltage to be applied to the motor as a function of the frequency	0 - 4 [1]		Each parameter value correspond to a different characteristic:		
				0	user-defined characteristic	P-02 P-04 P-70 P-71 P-72 P-73 P-74 P-84 b-16 b-32
				1	linear characteristic for 50 Hz motors	
				2	linear characteristic for 60 Hz motors	P-02 P-04 P-73 P-74 P-84
				3	quadratic characteristic for 50 Hz motors	b-16 b-32
4	quadratic characteristic for 60 Hz motors					


PARAMETER	FUNCTION	RANGE [DEFAULT]	DESCRIPTION
P-70	To customize the characteristic:	(P-71) - 480.0 [50.0] (Hz)	Selects the motor base frequency (rated); this frequency is associated to the motor max. voltage (max. V set via P-02 and P74).
P-71	the change is possible only if P-03 = 0	0 - (P-70) [25.0] (Hz)	Selects the intermediate frequency.
P-72		0 - (P-02) [(**)] (V)	Selects the voltage applied to the motor as regards the intermediate frequency.
P-02	Selects the max. voltage applied to the motor. Rating value of the motor V.	(P-72) - (**) [(**)] (V)	To make this value independent from the inverter supply voltage fluctuation enable the automatic adjustment function of the output voltage by setting b-32=1 . In this case, the inverter can be supplied through a voltage higher than the motor rated one. If b-32=0 then the voltage value set by P-02 must match the motor rated voltage.
P-04	Increases the output voltage at 0 Hz (% of P-02) and the torque.	0 - 30 [3]	The set voltage increase is added to the V/F characteristic in a decreasing way, until it is annulled at F= Fintermedia. (figure A)
P-73	Selects the freq. applied to the motor at start.	0 - 25.0 [0.0] (Hz)	It is the ramp begin frequency at the start and the ramp end frequency at the stop.
P-74	Limits the voltage applied to the motor (% of P-02).	0 - 100 [100]	The max. output voltage is limited to the value (P-74*P-02)/100.
b-16	Controls the voltage reduction set by P-74 parameter.	0=always; 1=con. speed only [0]	If b-16=0 the reduction is always active; if b-16=1 the reduction is not active during the ramps, so that the torque is completely available both in acceleration and deceleration state (figure B)
P-84	States the max. speed of voltage change	0.1 - 25.0 (s) [0.2]	Time needed to go from 0% to 100% of V and viceversa NOTE : too short times cause excessive current peaks.

[(**)] = The default value depends on the inverter size.




Freq. jumps - Output freq. limitations - Jogging - Switching freq. - Accel./decel. ramps																		
PARAMETER	FUNCTION	RANGE [DEFAULT]	DESCRIPTION															
P-34	Jump frequency N. 1	0.0 - 480.0 [0.0] (Hz)	Particular inverter frequencies can cause mechanical vibrations. The parameters P-34 P-35 and P-36 set two frequency bands which are crossed during the ramp phase but which can not be accepted as a normal frequency. If Fref decreases inside a prohibited area, the inverter uses a frequency set at the limit of the area defined via P-36. Ex.: the interval of the N.1 freq. goes from (P-34)-(P-36) to (P-34)+(P-36). To disable an interval set at 0 Hz the frequency of P-34 or P-35 The two intervals can overlap.															
P-35	Jump frequency N. 2	0.0 - 480.0 [0.0] (Hz)																
P-36	Frequency interval Δf on the left or right of the jump frequency	0.0 - 100.0 [0.0] (Hz)																
P-37	Upper limit of the output frequency (% of P-01)	(P-38) - 110 [100]	The output frequency can be limited independently of the maximum and minimum values defined by parameters P-01 and P-14. The output frequency can exceed the maximum frequency set by P-01 up to the max. value of 110%. This is done by using the slip compensation function or the speed feedback with the PID regulator.															
P-38	Lower limit of the output frequency (% of P-01)	0 - (P-37) [0]																
b-00	Selects the sequence followed by the RUN and REV together with the input Ix-JOG	0 = off - 1 = on [0]	JOGGING is a run control to advance the motor by small amounts. It applies preset freq. to the motor via param. F-08 with acc. and dec. ramps set via param. P-25, P-26. It does not allow DC current braking at startup or in stop condition. If b-00 = 0: RUN = run, REV = reversal, and the input Ix-JOG handles the jogging control. If RUN and Ix-JOG are simult. enabled the first one enabled will override the other one. If b-00 = 1: RUN = forward run, REV = backward run, the Ix-JOG enables the jogging control that overrides the normal run control.															
P-08	Switching freq. selection (executable with stopped motor only)	0 - 7 [5]	0 = 1kHz; 1 = 2 kHz; 2 = 3 kHz; 3 = 6 kHz; 4 = 9 kHz; 5 = 12 kHz; 6 = 15 kHz; 7 = 18 kHz. High values of the switching frequency reduce or eliminate the electric "noise" generated by the motor; viceversa, low values give a higher rotation fluidity at low speed, especially if high torques are required.															
b-33	Dead time comp.	0 = off - 1 = on [1]	Dead time compensation: it improves the torque and fluidity actions at low speed.															
b-36	It optimises the performance with low rev. if high switch. freq. are used.	0 = off - 1 = on [0]	In case of output frequencies below 5 Hz, a 3 kHz switching frequency is automatically selected.															
P-42	It configures the IN4 input	0-15	In order to use IN 4 and IN 5 as ramp selectors, P-42 and P-43 must acquire the value 5 (selector In T1) and 6 (selector In T2). The input state combined to the selectors In T1 In T2 defines one of the four possible ramp couples															
P-43	They configure the IN 5 input																	
P-07	It selects the ramp form	0.0 = linear 0.1s - 10.0 s = " S " shaped ramp	<table border="1"> <thead> <tr> <th>In T1</th> <th>In T2</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>accel./decel. ramp 1 (P05 = accel. time -P06 = decel. time)</td> </tr> <tr> <td>1</td> <td>0</td> <td>accel./decel. ramp 2 (P21 = accel. time -P22 = decel. time)</td> </tr> <tr> <td>0</td> <td>1</td> <td>accel./decel. ramp 3 (P23 = accel. time -P24 = decel. time)</td> </tr> <tr> <td>1</td> <td>1</td> <td>accel./decel. ramp 4 (P25 = accel. time -P26 = decel. time)</td> </tr> </tbody> </table>	In T1	In T2	DESCRIPTION	0	0	accel./decel. ramp 1 (P05 = accel. time -P06 = decel. time)	1	0	accel./decel. ramp 2 (P21 = accel. time -P22 = decel. time)	0	1	accel./decel. ramp 3 (P23 = accel. time -P24 = decel. time)	1	1	accel./decel. ramp 4 (P25 = accel. time -P26 = decel. time)
In T1	In T2	DESCRIPTION																
0	0	accel./decel. ramp 1 (P05 = accel. time -P06 = decel. time)																
1	0	accel./decel. ramp 2 (P21 = accel. time -P22 = decel. time)																
0	1	accel./decel. ramp 3 (P23 = accel. time -P24 = decel. time)																
1	1	accel./decel. ramp 4 (P25 = accel. time -P26 = decel. time)																
P-27	It selects the resolution through which the ramp times are defined	0 = 0.01 s - 99.99 s 1 = 0.1 s - 999.9 s 2 = 1 s - 9999 s [1]	<p>Note: a) 1= closed contact; the controls not used are considered in 0 state. b) When the jogging control Ix-JOG is active (page 28), the ramp pair 4 is automatically chosen. The acceleration and deceleration times are necessary to switch from zero Hz to the max. frequency, (P-01), and viceversa. c) The modification of P-27 can affect the values entered on P-01, P-02, P-21, P-22, P-23, P-24, P-25, P-26 so these values must be rechecked. d) The ramp extension can also be generated if the functions of motor stall and inverter lock are enabled. This actuation is signaled by a flashing GREEN LED and also on terminal board by properly programming OUT1.</p>															

Linear ramps and "S" shaped ramps



Motor data setting - Motor thermal protection - Prevention of motor stall - inverter lock			
PARAMETER	FUNCTION	RANGE [DEFAULT]	DESCRIPTION
P-09	Motor rated current (from the rating)	(20% - 150%) Inom. [Inom] (A)	To take advantage of the inverter/motor system features, it is necessary to set the characteristics of the motor used, through the parameters.
P-10	Sets the motor thermal constant	1 - (120) [20] (min)	P-10 can be calculated, (necessary only if the motor thermal protection function is enabled, par. b-06). The higher the value set, the higher the motor capacity of supporting currents higher than the rated one.
P-11	Motor cos φ (obtained from the rating)	0.01 - 1.00 [(**)]	The value of P-12 represents the motor phase resistance in case of star connection, or 1/3 of the phase resistance in case of delta connection. To get the proper value of P-12, use the function C-06:
P-12	Equivalent stator resistance	0.0 - 25.0 [0.0] (Ω)	- 1) Use M to select the C menu ON DISPLAY: <input type="text" value="C-00"/> - 2) Use the ↑, ↓ keys to select the code C-06 ON DISPLAY: <input type="text" value="C-06"/> and press E : the code C-06 is displayed ON DISPLAY: <input type="text" value="0"/> - 3) Use the ↑, ↓ keys to select the code 07 ON DISPLAY: <input type="text" value="7"/> and press E : the stator resistance is automatically measured. The display will confirm that the operation has been executed. (To see the measured value, read the value of P-12 that, if necessary, can be manually modified).
b-06	Enables the thermal protection of the motor	0 = off - 1 = on [1]	0 = standard motor, not servo-ventilated, at low revolution number not able to support the rated current (derating), the continuous current of DC braking is reduced by 50% (the motor is able to support a continuous current that is 50% of the rated one). 1 = servo-ventilated motor; specify the type of motor used through parameter b-07. The level reached by the protection can be read in d-10, measured in % of the max. thermic overload allowed for the motor. When this level reaches 100%, the protection trips and the inverter is locked.
b-24	Limits the acceleration current.		Excessive current or voltage can cause motor stall or inverter lock conditions due to protections tripping. The aim of the parameter is to set thresholds that, when exceeded, trip some actions that limit currents and voltages: b-24: if the threshold programmed through P-77 (in acceleration state and if f < P-70, constant torque zone), or through P-78 (in acceleration state and if f > P-70, constant power zone) is exceeded, the ramp is stopped until the current remains over this threshold. b-25: if the threshold programmed through P-79 is exceeded (constant speed operation) the output frequency is reduced at a rate controlled by P-82; as soon as I falls below the threshold the frequency start to increase with the selected ramp. b-26: the ramp is stopped when the voltage on filter capacitors is near the overvoltage threshold; when the V falls under the threshold the ramp starts again; NOTE : the function can be unable to prevent the inverter lock in case of high-inertia loads and short ramps. b-27: if the voltage on filter capacitors exceeds the overvoltage threshold, the output voltage is set to zero (corresponding to a coast-to-stop). As soon as the voltage reaches safety levels, a free rotation motor pickup is executed and the deceleration ramp is restarted. NOTE: too short ramps can lock the inverter by overvoltage.
b-25	Limits the current at constant speed.	0 = off - 1 = on [1]	
b-26	Limits the voltage during deceleration .	0 = off - 1 = on [1]	
b-27	Prevents overvoltage.	0 = off - 1 = on [1]	
P-77 P-78 P-79	The parameters set the current threshold as a % of Inom	0 = off - 1 = on [0]	
P-82	Set the deceleration ramp when b-25 is active	20 - 200 [170]	
P-85	Set max. ref. 8f after wich start the ramp state.	0.1 - 25 [0.5] (Hz)	The parameters allows to distinguish between the acceleration or deceleration state and the constant speed state . In fact, too short accel. ramps as regards the motor capacity, or slight reference variations, either intentional or not, does not mean the motor to be considered in constant acceleration or deceleration. The switching from one state to the other can be controlled through P-85, P-86: P-85 set the indifference range to reference change as regards the constant speed; P-86, instead, set the time after which, starting from ramp completion, the motor is in constant speed state.
P-86	Set the delay after wich the motor is considered in constant speed state.	0.1 - 25 [1] (s)	



Slip compensation - Instantaneous overload signalling - Prevention of short mains blackout - Pickup of motor in free rotation (flying restart) - Automatic boost

PARAMETER	FUNCTION	RANGE [DEFAULT]	DESCRIPTION
P-32	Defines value of the motor rated slip (%) $s=(n_0-n_{nom}) \cdot 100/n_0$	0.0 - 25.0 [0.0]	The parameters compensate for the motor speed reduction when increasing the applied load (slip), changing the inverter output frequency proportionally to the applied load. Note: a too quick response (P-33 too short) can cause fluctuations in the output frequency. To obtain a good compensation properly set P-09, P-11, P-12 and if the reference frequency is close to the maximum frequency, it is advisable to set on P-37 a value beyond 100%
P-33	Compensation time constant	0.0 - 10.0 [0.1] (s)	
b-17	Enable the overload detection function	0 = off - 1 = on [0]	The aim of the function which detects the overload is to signal or avoid excessive efforts on the load, causing the instantaneous locking of the inverter and the alarm signalling. The threshold defined by P-55 is in % of the motor rated load as obtained through parameters P-09, P-11.
b-18	Select when the detection function is active	0=always - 1= con. speed [0]	
b-19	Set the overload locked state	0 = off - 1 = on [0]	The threshold exceeding can be signalled through terminal board by configuring the Ox-GTT output.
P-55	Set the tripping level of the protection	20 - 200 [110] (%)	The parameter P-12 must be accurately set too.
P-56	Set the delay before the protection trip	0.1 - 25.0 [0.1] (s)	P-56 Set how long the overload can exceed the tripping threshold before the signalling and the inverter lock functions are enabled
b-28	Enables the prevention of short mains blackout	0 = off - 1 = on [0]	The parameters avoid locking the inverter when a short mains blackout happens. The mains cut off is stated on the display and on the terminal board by configuring one of digital outputs OUT1. Note: on single phase inverter it is advisable to reduce the P-75 value to the minimum to prevent excessive start-up currents. Otherwise it is possible that the inverter locks by undervoltage. The alarm is always enabled if the voltage falls under a given value that depends on the inverter size; the tripping of the prevention function sets the output voltage to zero, (coast-to-stop). In this way, the filter capacitors are not completely discharged thus keeping the control logic active. As soon as the voltage exceeds the threshold (hysteresis of 6%), a pickup phase of motor in free rotation is performed, thus resetting the speed in force before the tripping.
P-75	Determines the undervoltage protection tripping threshold	40 - 80 [70] (% di P-02)	
P-76	Set the max. duration of the short mains blackout before the alarm is enabled	0.1 - 25.0 [1] (s)	
b-29	Enables the tripping of the motor pickup	0 = off - 1 = on [0]	The aim of the pickup function of motor in free rotation is to avoid too high start-up currents generated when, for some causes the inverter cuts the voltage to the motor, then a subsequent run command makes a start from zero Hz with the motor still rotating. This function generates an initial frequency, b-30, equal to or higher than the motor one, by gradually increasing, P-84, the output voltage to 100 % and controlling that the current does not exceed a preset threshold set by P-80, (it is advisable that this value should be slightly higher than the current absorbed by the motor) otherwise the output frequency would be reduced and the voltage would be limited. The delay between the cut off of the motor voltage and when the motor pickup phase start can be controlled by P-81 (demagnetization time). The motor is considered frequency-locked when a given frequency is reached so that, at full voltage, the current is under the threshold. The motor can then be accelerated or decelerated until the reference is reached. b-23 enables the use of a frequency obtained from an encoder as initial frequency for motor pickup. The motor pickup function can be enabled through terminal board by configuring one of the inputs as Ix-FLY input. If the Ix-FLY input is active, every time the run control is pressed the motor pickup is performed.
b-30	Selects the initial scanning frequency	0=ref. freq. 1=max. freq. [0]	
b-31	Enables the function with the first run control after startup	0 = off - 1 = on [0]	
P-80	Sets the max. current threshold during the motor pickup phase	20 - 200 [120] (% di Inom)	
P-81	Delay to activate the motor pickup function	0.01 - 10.00 (s)	
P-83	Sets the rate of change of the frequency during the lock search	0.1 - 25.0 [1] (s)	
P-84	Set the max. rate of change of the voltage	0.1 - 25.0 [0.2] (s)	
b-34	Enables the automatic boost.	0 = off - 1 = on [0]	This function is an alternative to the voltage (and torque) boost obtained through parameter P-04 (pag. 23). The output voltage is automatically increased as regards the motor and the connected load characteristics. The efficiency of the action depends on the accuracy applied when setting the parameters P-09, P-11, P-12. If the programming phase is not performed in the right way, some oscillations may occur

Programmable and non-programmable control inputs

INPUT TERM.No.	NAME	FUNCTION		DESCRIPTION
1	REV	Se b-00=0	Run reversal	Terminals 1, 2, 3, have pre-defined functions; the other five can be configured through parameter P-42, P-43 . If the forward and backward run controls are simultaneously executed (b-00=1) a stop control effect is generated: the rotation reversal is obtained by decelerating, with selected ramp, up to a zero frequency, then accelerating up to the preset reference frequency.
2	RUN		Back. run	
			For. run	
3	EXTFLT	Alarm coming from outside		
4	IN5	Configurable digital inputs		
11	IN4			

Configuration of the configurable digital inputs via: **P-42** (IN 4) and **P-43** (IN 5):

PARAMETER VALUE	NAME	CONTROL DEFAULT STATE	PERFORMED ACTION	NOTE: If no input is configured to enable (disable) a control, this control is automatically considered as active (inactive) as shown on the column DEFAULT STATE.
0	In RES	Not active	Resets the alarms (default function for P-43 on the IN 5 input)	
1	In SF1	"	Reference frequency selectors as set by F-xx (page 17) must not be used	
2	In SF2	"		
3	/	/		
4	In JOG	Not active	Jogging control (default function for P-42 on the IN 4 input)	
5	In T1	"	Acceleration/deceleration ramp selectors (page 24)	
6	In T2	"		
7	In DE	Active	Motor output enabling (if disabled, causes a coast-to-stop)	
8	In DD	Not active	Motor output disabling (if enabled, causes a coast-to-stop)	
9	In ENB	Active	D.C. braking enabling	
10	In DCB	Not active	D.C. braking control	
11	In FLY	Not active	Enables the motor pickup function in free rotation (flying restart)	
12	In INC	Active	Enables the ramp execution	
13	In DEC	Not active	Enables the ramp deceleration till zero Hz	
14	In PID	Active	PID regulator enabling	
15	In P12	Not active	Selector of PID regulator coefficients	
16	In IM	"	Motorized potentiometer value increase	
17	In DM	"	Motorized potentiometer value decrease	

The combined parameters, corresponding to single controls, are active through the following actions:

PARAMETER	FUNCTION	VALUE [DEFAULT]	DESCRIPTION
b-01	Sets stop condition	0	The control causes a ramp deceleration up to zero Hz
		1 [0]	The control cuts off the voltage to the motor so that it coasts-to-stop
b-02	Enables motor reversal	0	Disables the control for motor rotation reversal
		1 [1]	Enables the control for motor rotation reversal
b-03	Safety	0	The safety command for run control is disabled
		1 [1]	Enables the safety command for run control (*)
b-08	Set the state of external alarm IN Set	0	Sets the input as normally open (N.O.).The contact closure generates the alarm state
		1 [0]	Sets the input as normally closed (N.C.).The opening generates the alarm state
b-09	external alarm action	0	The alarm state caused by EXTFLT locks the inverter (released only through a reset)
		1 [0]	The alarm state caused by EXTFLT disables the motor while the control is active
b-10	External alarm detection mode	0	Allows the inverter to detect the external alarm at any moment
		1 [0]	Allows the inverter to detect the external alarm only if the motor is running
b-11	Extern. alarm reset management	0	If EXTFLT causes the inverter lock, a manual reset only can be executed
		1 [0]	If EXTFLT causes the inverter lock, an automatic reset can be executed if b-12=1
b-39	Term. board control management	0	Ignores the controls from terminal board (except EXTFLT, Ix-DE, Ix-DD)
		1 [1]	Enables the control from terminal board

(*) If the "Safety" command is active, the inverter, before starting, has to detect a switching from a non-active to an active state of the run command.


Relay output (OUT-1) - Dynamic braking

P - 44 VALUE	FUNCTION NAME	EVENT DISPLAYED BY THE DIGITAL OUTPUT (ACTIVE OUTPUT)		NOTES
0	Out OK	Inverter in ready state		The available output on relay (OUT1) terminals 16,17,18 can be configured, via the meanings listed in the table, through the parameter P-44 The output is active when the event listed in the table occurs. (*) Means that during start-up the outputs are inactive: the outputs will be active not before that the PID regulator error comes into the tolerance limits at least once.
1	Out AL	Inverter in alarm state		
2	Out RUN	The motor is running		
3	Out STP	The motor is not running		
4	Out REV	Counter-clockwise rotation (in the opposite case, the output is not active)		
5	Out STD	Inverter in steady state (end of ramp)		
6	Out RMP	Ramp in progress		
7	Out EQF	Output frequency = programmed frequency P-53 , with hysteresis P-54		
8	Out NEF	Output frequency ≠ programmed frequency P-53 , with hysteresis P-54		
9	Out GTF	Output frequency > programmed frequency P-53 , with hysteresis P-54		
10	Out LTF	Output frequency < programmed frequency P-53 , with hysteresis P-54		
11	Out RN1	Ramp end (disabled when the output freq. is < programmed freq. P-53)		
12	Out RN2	Output frequency < programmed frequency P-53 (disabled at ramp end)		
13	Out UV	Undervoltage with running motor (not depends from short mains blackout)		
14	Out GTT	Output torque > the torque set via P-55		
15	Out IL		current	
16	Out VL	In case of ramp extension for limitation of:	voltage	
17	Out IVL		current or voltage	
18	Out FLY		When the motor pickup occurs	
19	Out BRK	The dynamic braking circuit is faulty		
20	Out CFI	The cos φ sign is negative		
21	Out ERP	the PID regulator error is	> (P-91) e < -(P-92)	
22	Out EPP		> (P-91)	
23	Out EPN		< -(P-92)	
24	Out ERP(*)	the PID regulator error is	> (P-91) e < -(P-92)	
25	Out EPP(*)		> (P-91)	
26	Out EPN(*)		< -(P-92)	
27	Out ERV	not used		
28	Out EFW			
29	Out EST			
30	Out ERN			
31	Out EF	States the intervention of external alarm		
32	Out EFN	Denied value of Out EF		
33	Out SIU	Detects the current signal in the U phase		
34	Out SIV	Detects the current signal in the V phase		
35	Out SIW	Detects the current signal in the W phase		

Dynamic braking

PARAMETER	FUNCTION	VALUE [DEFAULT]	DESCRIPTION
b-20	Thermic protection of the braking resistor	0 = off 1 = on [0]	b-20=1 enables the thermic protection of the braking resistor. The protection efficiency depends on the accuracy of parameters P-62 , P-63 , P-64 . The reached protection level can be displayed through parameter d-11 , expressed in %. When the level reaches 100%, the protection locks the inverter. During the braking phase, in case of shortcircuit of the inner braking device, the corresponding signalling can be displayed through terminal board by properly configuring the Ox-BRK output. The only action to be performed in case of shortcircuit is to cut the inverter supply off. NOTE: The wiring terminals of the braking resistor are NOT short circuit PROTECTED or protected by improper value (lower than minimum expected) of the resistors used : in these cases the inverter will be permanently damaged.
P-62	Ohmic value of the braking resistor (Ω)	1 - 250 [(**)]	
P-63	Resist. power of the braking resistor (W)	10 - 2500 [(**)]	
P-64	Thermic constant of the braking resistor (s)	5 - 1250 [(**)]	

Analog output (OUT-AN) - Direct current braking


P - 48 VALUE	TYPE AND MEANING OF THE ANALOG OUTPUT	NOTES
0	Voltage proportional to the output frequency; full scale value set by P-01.	The output voltage at terminal N.° 12 of the control terminal board can vary between 0 and 10V. The meaning assumed by this voltage depends on the value assigned to parameter P-48. The value of the voltage can be changed by properly programming the parameters P-49, P-50, P-51. 
1	10V-amplitude square wave with frequency equal to the output frequency.	
2	10V-amplitude square wave with frequency twice the output frequency.	
3	Voltage proportional to the output current; the full scale value is twice the rated I.	
4	Voltage proportional to the output voltage; full scale value set by P-02.	
5	Analog voltage proportional to the output torque (positive only); the full scale value is twice the rated T.	
6	Analog voltage proportional to the output torque (absolute value); the sign can be obtained by one of the digital outputs.	
7	Analog voltage proportional to the output power (positive only); the full scale value is twice the motor rated power	
8	Voltage proportional to the output power (absolute only); sign obtainable by one of the digital outputs; the full scale value is twice the motor rated power.	
9	Voltage proportional to the output cos φ (only positive); the full scale value is 1	
10	Voltage proportional to the output cos φ (absolute value); the sign can be obtained by the digital output.	
11	/not used	
12	Voltage proportional to the reference frequency	
13	Voltage proportional to the current in the U phase	
14	Voltage proportional to the current in the V phase	
15	Voltage proportional to the current in the W phase	
16	Voltage proportional to the active current I*cos φ	
17	Voltage proportional to the magnetizing current I*sen φ	

- 1: offset (P-49) = 3; gain (P-50) = 1
- 2: offset (P-49) = 0; gain (P-50) = 1
- 3: offset (P-49) = -5; gain (P-50) = 1
- 4: offset (P-49) = 10; gain (P-50) = -1
- 5: offset (P-49) = 10; gain (P-50) = -2

PARA METER	FUNCTION	VALUE [DEFAULT]
P - 49	Adds a variable offset to the signal chosen by P-48	- 9,99 / +9,99 [0,00] (V)
P - 50	Controls the gain of the analog output	- 9,99 / +9,99 [1,00]
P - 51	Changes the time constant of the analog output filter	0,00 / 2,50 [0,00] (s)

$$V_{out} = 10 \left[\left(\frac{S_{int}}{S_{fsc}} \right) (P-50) + (P-49) \right]$$

PARA METER	FUNCTION	VALUE [DEFAULT]	DESCRIPTION
P - 28	D.C. braking level (% of P-09)	0 - 100 [0]	Defines the D.C. value expressed in % of P-02 from which the value of the braking current depends.
P - 29	Limit frequency below which the braking is forced (Hz)	0,0 / 480,0 [0,0]	Defines the frequency below which the decel. ramp is locked and the braking current is forced. Before forcing the current, Vout is set to zero for a time defined by parameter P-81 (demag. time).
P - 30	Set the braking duration at start-up (s)	0,0 / 60,0 [0,0]	Defines the braking duration at start-up; if P-30 = 0 → no braking is made at startup.
P - 31	Set the braking duration in stop phase (s)	0,0 / 60,0 [0,0]	Determines the braking duration in stop phase; if P-31 = 0 → no braking is made in stop phase.



The aim of D.C. braking is to keep the motor locked in a fixed position, it is not an alternative to the ramp deceleration. The D.C. braking consist in forcing a direct current that depends from the voltage set by P-28 and the electrical characteristics of the motor into a motor phase.

With D.C. braking, the deceleration time is shorter than in case of coast to stop. Sometimes, at start-up, it may be useful to lock the motor for a preset time before starting the acceleration ramp.

The function can also be enabled or disabled through terminal board by configuring one of the programmable inputs (Ix-ENB) as a control.

It is always possible to force a direct current on the motor, independently of the values assumed by the parameters, by configuring one of the terminal board programmable inputs (Ix-DCB) as control of D.C. braking.

During the D.C. braking, at parameter d-00 the display shows the message " dcb " instead of the frequency.

PID regulator																																																																																			
PARAMETER	FUNCTION	VALUE [DEFAULT]	DESCRIPTION																																																																																
b-40	PID regulator enabling	0 = off 1 = on [0]	The regulator is active with running motor only.																																																																																
b-41	Disables the regulator in ramp phase	0=off 1=on [0]	1 interrupts the regulator action during the ramp phase.																																																																																
b-42	/																																																																																		
b-43	Select the controlled parameter	0=frequency 1=voltage [0]	0 : the regulator controls the output frequency; full scale value defined by P-01 ; 1 : controls the output voltage; full scale value defined by P-02 ;																																																																																
b-44	Reverts the error sign	0 = off 1 = on [0]	The sign of the error signal between reference and feedback is reversed (and the adjustment effect too).																																																																																
b-45	Regulation mode	0=direct 1=sum (feed/forw) [0]	1 :the reg. output is added to the freq. reference value or to the voltage value provided by the V/F characteristic; 0 : the output act as set by b-43 .																																																																																
b-46	Suppress the regulator positive output	0 = off 1 = on [0]	Limits the regulator output in the positive direction; 0 allows the output to assume positive values too.																																																																																
b-47	Suppress the regulator negative output	0 = off 1 = on [0]	Limits the regulator output in the negative direction; 0 allows the output to assume negative values too.																																																																																
b-48	Suppress the integral term	0 = off 1 = on [0]	Allows the integral term to match the limits set to the output by b-46 and b-47 .																																																																																
b-49	Initialisation of the integral term at start-up	0 = off 1 = on [0]	Allows the initialization by means of the run control. NOTE : this could cause a very slow response of the regulator, even with high gains.																																																																																
P-90	PID reference (%)	0.0 - 100.0 [0.0]	The reference value is derived through the setting of the selector parameters shown on the following table.																																																																																
P-91	PID maximum positive error (%)	0.1 - 100.0 [5.0]	Defines the max. positive excursion of the regulator error expressed in % of the full scale value.																																																																																
P-92	PID maximum negative error (%)	0.1 - 100.0 [5.0]	Defines the max. negative excursion of the regulator error expressed in % of the full scale value																																																																																
P-93	PID update time(s)	0.00(=0.005s) - 2.50 [0.00]	Defines the regulator update time.																																																																																
P-94	Proportional term gain Kp1	0.00 - 99.99 [0.00]	The regulator enabling and the coefficients selection can be made through terminal control board by configuring two out of the five control inputs as Ix-PID and Ix-P12 input respectively: Ix-PID = 1 the PID regulator is controlled from the terminal board. Ix-P12 = 1 selects the coefficient set N. 1; 0 refers to set 2. When enabling the regulator or changing the coefficients set, the integral term is used according to the present output and coefficients, by taking into account possible limits applied to the output and to the integral term; this avoid sudden output changes ("bumpless" operation). If the coefficient change occurs when the error is significant, the system response speed is affected by the integral action weight, as the proportional and derivative term weight is compensated by the integral term. A max. tolerance interval can be defined for the error that, if exceeded, actuates a signalling available on the terminal board by properly configuring one of the digital output OUT1 . The error tolerance control is enabled when the error falls within the preset interval for the first time (P91 and P92) such a condition can be displayed via P46= 21,22, 23. During start-up transient (that is: not before the regulator error falls within the tolerance limits at least once), it is possible to disable the outputs through P-46 value 24, or 25, or 26. The possible sign reversal made by setting b-44=1 has no importance for tolerance control. The out-of-tolerance signalling available on the digital outputs can be enabled when exceeding one of the two limits (Ox-ERP), or the positive (Ox-EPP) or negative (Ox-EPN) limit only. To facilitate the parameters setting, the following items can be displayed: reference signal: code d-22 on display, feedback signal: code d-23 , " error: code d-24 , " integral component: code d-25 , " output: code d-26 , " NOTE: The integral term is set to zero if the integral action time is set to the max. value, i.e. 99.99. The derivative term is null if the derivative action time is set to zero.																																																																																
P-95	Integral action time Ti1	0.00 - 99.99 [99.99]																																																																																	
P-96	Derivative action time Td1	0.00 - 99.99 [0.00]																																																																																	
P-97	Proportional term gain Kp2	0.00 - 99.99 [0.00]																																																																																	
P-98	Integral action time Ti2	0.00 - 99.99 [99.99]																																																																																	
P-99	Derivative action time Td2	0.00 - 99.99 [0.00]																																																																																	
		<table border="1"> <thead> <tr> <th colspan="4">feedb. switches</th> </tr> <tr> <th></th> <th>b-55</th> <th>b-54</th> <th>b-53</th> </tr> </thead> <tbody> <tr> <td>set at 0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>/</td> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>/</td> <td>0</td> <td>1</td> <td>0</td> </tr> <tr> <td>REF-V</td> <td>0</td> <td>1</td> <td>1</td> </tr> <tr> <td>REF-I</td> <td>1</td> <td>0</td> <td>0</td> </tr> <tr> <td>I out (10V=2*Inom)</td> <td>1</td> <td>0</td> <td>1</td> </tr> <tr> <td>T out (10V=2*Tnom)</td> <td>1</td> <td>1</td> <td>0</td> </tr> <tr> <td>P out (10V=2*Pnom)</td> <td>1</td> <td>1</td> <td>1</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="4">ref. switches</th> </tr> <tr> <th></th> <th>b-52</th> <th>b-51</th> <th>b-50</th> </tr> </thead> <tbody> <tr> <td>ref. frequency</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>/</td> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>/</td> <td>0</td> <td>1</td> <td>0</td> </tr> <tr> <td>REF-V</td> <td>0</td> <td>1</td> <td>1</td> </tr> <tr> <td>REF-I</td> <td>1</td> <td>0</td> <td>0</td> </tr> <tr> <td>P-90 parameter</td> <td>1</td> <td>0</td> <td>1</td> </tr> <tr> <td>freq. downstr.r. gen.</td> <td>1</td> <td>1</td> <td>0</td> </tr> <tr> <td>set at 0</td> <td>1</td> <td>1</td> <td>1</td> </tr> </tbody> </table>	feedb. switches					b-55	b-54	b-53	set at 0	0	0	0	/	0	0	1	/	0	1	0	REF-V	0	1	1	REF-I	1	0	0	I out (10V=2*Inom)	1	0	1	T out (10V=2*Tnom)	1	1	0	P out (10V=2*Pnom)	1	1	1	ref. switches					b-52	b-51	b-50	ref. frequency	0	0	0	/	0	0	1	/	0	1	0	REF-V	0	1	1	REF-I	1	0	0	P-90 parameter	1	0	1	freq. downstr.r. gen.	1	1	0	set at 0	1	1	1	
feedb. switches																																																																																			
	b-55	b-54	b-53																																																																																
set at 0	0	0	0																																																																																
/	0	0	1																																																																																
/	0	1	0																																																																																
REF-V	0	1	1																																																																																
REF-I	1	0	0																																																																																
I out (10V=2*Inom)	1	0	1																																																																																
T out (10V=2*Tnom)	1	1	0																																																																																
P out (10V=2*Pnom)	1	1	1																																																																																
ref. switches																																																																																			
	b-52	b-51	b-50																																																																																
ref. frequency	0	0	0																																																																																
/	0	0	1																																																																																
/	0	1	0																																																																																
REF-V	0	1	1																																																																																
REF-I	1	0	0																																																																																
P-90 parameter	1	0	1																																																																																
freq. downstr.r. gen.	1	1	0																																																																																
set at 0	1	1	1																																																																																

Reset - Autoreset - Protections and alarms			
FUNCTION	DESCRIPTION		
Reset	<p>Operation to be executed when the inverter is in alarm state. Three possibilities are available:</p> <p>a) <u>Keyboard reset</u>: simultaneously press the \uparrow and \downarrow keys; the action will have effect when the keys are released.</p> <p>b) <u>Terminal board reset</u>: it can only be performed if one of the programmable control inputs has been configured as Ix-RES. In this case, the reset operation is enabled when switching from active to inactive control.</p> <p>c) <u>Cut the inverter supply off</u> wait until it is completely off, supply the inverter again.</p>		
Autoreset	As an alternative to manual reset, this function allows an automatic restart in case of lock due to protection tripping. It can only be enabled if the lock is due to: overcurrent, overvoltage, undervoltage, momentary overload, external alarm (b-11) and is controlled by the parameters defined on the following table:		
PARAMETER	FUNCTION	VALUE [DEFAULT]	DESCRIPTION
b-12	Autoreset enabling	0 = off 1 = on [0]	In case of lock, it automatically restarts the inverter.
b-13	Enable autoreset attempts limitation	0 = off 1 = on [0]	Allows to limit the number of attempts made by the inverter to execute the autoreset.
b-14	Enable the automatic set at zero the number of attempts	0 = off 1 = on (10min.) [0]	Sets to zero the number of attempts performed, if no further locks occur within 10 min.
b-15	Set the state of the alarm contact during the autoreset.	0 = off 1 = on [1]	During autoreset, it disables the lock signalling contacts on the terminal board if allowed, through parameter setting, to perform the alarm function.
P-57	Delay to start the autoreset function (s)	0.1 - 60.0 [5]	Defines the time, as regards the lock enabling moment, after which the autoreset (restart) is executed.
P-58	Set the max. number of restart attempts	1 - 250 [1]	Sets the max. number of restart attempts after which the inverter remains in lock state. To restart, execute a manual reset.

CODE ON DISPLAY	FUNCTION	DESCRIPTION	CODE
C.Err	Full lock	Configuration memory error. It is enabled at inverter startup if the configuration memory is not working properly. To avoid this, try to turn the inverter off and restart it after some minutes.	
P.Err		Parameter memory error. It is enabled if the memory contains inconsistent parameters. Causes: accidental loss of parameters (turning off during storage phase), memory failure. In case of accidental loss: turn the inverter off and restart it after some minutes. The factory-preset parameters will be stored.	
EF	Lock that can be reset (alarm contact enabling and storage of alarm type, the display is flashing)	External protection: enabled by the EXTFLT input on terminal board. Autoreset can be enabled only if parameter b-11=1 .	1
OC		Overcurrent protection: enabled when the output current exceeds, even momentary, the max. allowed threshold to protect the inverter. It signals shortcircuits between phases and to ground too.	2
OU		Overvoltage protection: enabled when the voltage at the filter capacitor ends exceeds the max. programmed threshold to protect the inverter.	3
UU		Undervoltage protection: enabled when the voltage at the filter capacitor ends falls below the min. threshold programmed to avoid troubles due to torque reduction. Autoreset is allowed. If b-37=0 , the alarm storage is disabled.	4
OH		Overtemperature protection: enabled when the heat sink temperature exceeds the max. threshold programmed to protect the inverter. Autoreset is not allowed.	5
OLI		Inverter overload protection: enabled when the direct current exceeds the max. threshold for the max. allowed time (I_xT) to protect the inverter. Autoreset is not allowed.	6
OLN		Motor overload protection: enabled when the direct current exceeds the max. threshold for the max. allowed time (I²xT), to protect the motor. The levels and times depend on setting of the motor characteristic data. Autoreset is not allowed.	7
OLr		Braking resistor overload protection: enabled when the power dissipated by the braking resistor exceeds the max. threshold for the max. allowed time. The levels and times depend on setting of the resistor characteristic. Autoreset is not allowed.	8
Ot		Protection for momentary motor overload: it is active, after enabling (b-17=1), when the torque delivered by the motor exceeds the programmed level for the preset time, to protect the connected mechanical parts or the worked material.	9
FU		Fuse breakage protection: enabled in case of inner fuse breakage. Autoreset is not allowed.	11

Note: code 10 is not used

Serial line

DESCRIPTION

The inverter can communicate with a remote controller through a RS-485 2-wire serial line. In this case, the inverter behaves like a "slave", i.e. it answers on special controller request only (master). Up to 32 inverters can be parallel connected with addresses set between 1 and 99 through **P - 68**.

The address **99** is a specialized one since it is expected that it will be used when it is necessary to send a code to all inverters simultaneously; in this case the reception of the code is assured to all inverters regardless of the individual address, the acknowledgement will be made only from the inverter with address 99.

The serial line allows to read and write all the parameters, forcing the various controls by replacing the keyboard or the terminal board, or forcing the I/O as in a PLC. The parameters involved are:


PARAMETER	FUNCTION	VALUE [DEFAULT]	DESCRIPTION
P - 65	Enables the input control via serial line	0 - 255 [0]	The parameter value is a decimal equivalent of the current value of the 8 bit input register SX8 (see the serial communication handbook)
P - 66	Enables the output control via serial line	0 - 15 [0]	The parameter value is a decimal equivalent of the current value of the 8 bit ooutput register SX8 (see the serial communication handbook)
P - 67	Defines the transmission param.	0 - 19 [1]	See the following table
P - 68	Assign an address to each inverter	0 - 99 [0]	Assign the unique address between 0 - 99 to each inverter
P - 69	Set the response delay time of the inverter	0 - 250 [1] (ms)	The delay time between the receipt of the comand and the emission of the answer
b - 39	Enables the terminal board control	0 = off 1 = on [1]	The scope of the parameter is to disable the control of the inverter from the terminal board to avoid conflicts with the serial line.
P - 89	Serial link time-out	0,0-25,0 [0,0]	If set at 0,0 it disables the function

P-67 VALUE	BAUD RATE	DATA BIT	PARITY	STOP BIT	P-67 VALUE	BAUD RATE	DATA BIT	PARITY	STOP BIT
0	9600	7	even	1	10	2400	7	no	2
1	9600	7	odd	1	11	2400	8	no	1
2	9600	7	no	2	12	1200	7	even	1
3	9600	8	no	1	13	1200	7	odd	1
4	4800	7	even	1	14	1200	7	no	2
5	4800	7	odd	1	15	1200	8	no	1
6	4800	7	no	2	16	19200	7	even	1
7	4800	8	no	1	17	19200	7	odd	1
8	2400	7	even	1	18	19200	7	no	2
9	2400	7	odd	1	19	19200	8	no	1


Auxiliary analog input (AUX-V) - Analog output (OUT-AN)

P - 47 VALUE	ACTION PERFORMED
0	No action
1	Frequency reference (active if InSF1 =on, InSF2 =off); the frequency changes in a linear way from 0 Hz to P-01 .
2	Adjusts the output voltage reduction by a proportional value ranging between 20% and P-74 .
3	Adjusts the braking direct current, whose level proportionally changes between 0 and P-28 .
4	Sets the torque threshold; the threshold value proportionally changes between 20 and P-55 .
5	Extension factor of acceleration/deceleration ramps; proportionally changes between 1 and 10.
6	Extension factor of acceleration ramps only; proportionally changes between 1 and 10.
7	Extension factor of deceleration ramps only; proportionally changes between 1 and 10.
8	Changes the frequency reference in a positive way only: to the reference is added a frequency that proportionally changes between 0 and P-52 .
9	Changes the frequency reference: to the reference is added a frequency that proportionally changes between -P-52 and +P-52 .
10	Adjusts the boost level; the level proportionally changes between 0 and P-04 .
11	Gain of the frequency reference (In-Analog)

Note: The action generated by the analog voltage, variable from 0 and 10 V, applied to terminal 14 depends on the value assigned to parameter **P-47**.



Programming key [code QUIXPRG]



The programming key device allows to transfer parameters from and to the QUIXDrive inverter or between inverters. The data are stored in a E²PROM type memory, so battery backup is not necessary. The switch put on the key upper front side allows to protect the stored data against possible writing procedures. To copy the data from an inverter to the key or viceversa the keypad panels are used.

Programming key: Use method

- Parameter transmission from the key to the inverter:

- plug the key into the suitable connector (see page 36)
- select, via the keypad, the **C - 04** parameter, choose the code **7** and press **E**


If the key contains invalid parameters, the factory-preset parameters will be used and the message " Err ", will be displayed for 4 sec. Otherwise, data will be permanently stored and the confirmation message " done " will be displayed for 2 sec.

- Parameter transmission from the inverter to the key:

- plug the key into the suitable connector (see page 36)
- select, via the keypad, the **C - 05** parameter, choose the code **7** and press **E**

If the key is write-protected, the control is interrupted and the message " off " is displayed for 4 sec. Otherwise, the inverter parameters are stored on the key and, at the end of the operation, the message " done " will be displayed for 2 sec. to confirm the operation.

Remote terminal [code QUIXREM]



The remote terminal allows the connection to the inverter, QUIXDrive single phase series, through a 2-wire RS 485 serial line with a programmable Baud Rate.

The serial connection allows the remote terminal to control up to 32 inverter. The remote terminal supply needs +8/+24 Vdc, available on the terminal board .

Operator interface :


- 16 character LCD alphanumeric display, possibly backlighted.
- 8 keys to program and control the inverter. The STOP, FWD, JOG, and REV keys performs the direct operation of run and stop of an inverter enabled to do so.
- 4 signalling Led .

A 4-wire terminal block is provided to link the remote terminal to inverters .

(For the detailed instructions see the specific handbook)

- Wiring the Remote Terminal:

Correspondence between the terminals of the Remote Terminal and those of the inverter control circuit:



The inverter and remote terminal factory-preset parameters are in a position to grant the correct link working.

The QUIXDrive inverters are designed in accordance to all provisions of the **89 / 336 / EEC Directive** and **CE** Marking requirements.

The aim of the Directive is to avoid the products causing harmful interference and, at the same time, to ensure that the products will perform adequately and safely under electromagnetic interference.

The QUIXDrive inverters are electrical equipments designed to control the speed of A.C. motors and they can be installed in cabinets or inside a machinery.

The QUIXDrive inverters can be powered by an industrial AC mains source or by a residential one, but the inverter is not to be considered as a household tool; therefore it cannot be installed near other household appliances.

The end user is responsible, when installing the inverter, for the compliance with the EMC directives.

If the indicated prevention measures are implemented, the inverter can be normally installed without problems concerning EMI.

Standard or norms which QUIXDrive inverters are compliant to:

- Immunity

IEC 801 - 2	electrostatic discharge	8 kV contact 14 kV in air	IEC 1000 - 4 - 3	high frequency EM fields	10 V/m
IEC 801 - 4	burst on power supply cables	4 kV 5 kHz	IEC 1000 - 4 - 5	surge phase to phase	1 kV
	burst on control cables (capacitive coupling)	2 kV 5 kHz	IEC 1000 - 4 - 8	surge phase to ground	2 kV
IEC 801 - 4	burst on connection cables keyboard QUIX-TST, QUIX-REM (capacitive coupling)	2 kV 5 kHz		50 Hz EM field	200 A/m

- High frequency emissions

- Voltage disturbance on power supply cables:

The inverters belonging to the QUIX V (all versions) and QUIX F (versions QUIXF-2M-....-A) series are supplied with an internal filter according to the **EN 55011 (CISPR11) class A** in the frequency range 150 kHz ÷ 30 MHz.

The compliance to the **EN 55011 (CISPR11) class B** requires:

- a) the use of an external filter (see table) to be connected in series to power supply the cables
- b) the connections between inverter-motor, and inverter-supply system must be shielded
- c) a toroid must be put on each cable


- EM emitted disturbance:

As for this parameter:

- those devices with an internal filter (versions : QUIXF-2M-....-A , QUIXV-2M-....) are compliant to **EN 55011 (CISPR11) group 1 class A** in the following frequency range: 30 MHz, 1 GHz.
- the devices supplied with an external filter (see table) are compliant to **EN 55011 (CISPR11) group 1 class B** in the following frequency range: 30 MHz, 1 GHz.


Model	Filter	
	Type	Code
QUIX..-2M-0004	FF 0,75-Q2	S6F42
QUIX..-2M-0007	FF 0,75-Q2	S6F42
QUIX..-2M-0011	FF 1,5-Q2	S6F43
QUIX..-2M-0015	FF 2,2-Q2E	S6F47
QUIX..-2T-0004	FF 0,75-Q3E	S6F51
QUIX..-2T-0007	FF 4,0-Q3E	S6F52
QUIX..-2T-0011	FF 4,0-Q3E	S6F52
QUIX..-2T-0015	FF 4,0-Q3E	S6F52

Identification of the different installation sections



External dimensions

(values in mm)



SIEI



www.siei.it

QUIXDrive S0 -HM 04/00
Ver 2.1 / 25.05.2001



1S9A58